




# HS-1RP - External Enclosure



- |     |                      |     |                             |
|-----|----------------------|-----|-----------------------------|
| 1.  | Top Cover            | 17. | Access Panel                |
| 2.  | Front Header         | 18. | Side Door                   |
| 3.  | Header Panel Side    | 19. | Header Panel Side           |
| 4.  | Operator Door        | 20. | Rear Apron                  |
| 5.  | Right Front Panel    | 21. | Access Panel                |
| 6.  | Right Apron          | 22. | Access Panel                |
| 7.  | Right Side Pan       | 23. | Access Panel                |
| 8.  | Front Pan            | 24. | Rear Pan                    |
| 9.  | Front Coolant Trough | 25. | Left Side Panel             |
| 10. | Motor Cover          | 26. | Rear Panel                  |
| 11. | Left Front Door      | 27. | Right Side Panel            |
| 12. | Right Front Door     | 28. | Upper Bellow Guide          |
| 13. | Left Front Panel     | 29. | Chip Trough Extension Cover |
| 14. | Aprons Access Cover  | 30. | Chip Trough Extension       |
| 15. | Left Apron           | 31. | Chip Strainer               |
| 16. | Left Side Pan        | 32. | Discharge Chute             |