




# HS-2RP - External Enclosure



1. Rear Top Cover
2. Front Top Cover
3. Front Header
4. Right Bottom Door Track
5. Right Top Door Track
6. Right Rear Panel
7. Right Intermediate Panel
8. Right Side Header
9. Right Front Panel
10. Operator Door
11. Operator Door Window
12. Operator Door Window Gasket
13. Operator Door Window Frame  
Top-Bottom
14. Operator Door Window Frame  
Sides (2)
15. Right Side Apron
16. Right Front Door
17. Left Front Door
18. Coolant Trough
19. Discharge Chute
20. Left Side Apron
21. Left Front Panel
22. SMTC Door
23. SMTC Door Window
24. SMTC Door Window Gasket
25. SMTC Door Window Frame (4)
26. SMTC Front Support Panel
27. SMTC Front Panel Splash Shield
28. SMTC Rear Panel Splash Shield
29. SMTC Bottom Support Panel
30. SMTC Door Panel
31. SMTC Door Rail (2)
32. SMTC Door Shipping Bracket
33. SMTC Door Trip Bracket
34. Cylinder Rod Attach Bracket
35. SMTC Chip Shield Panel
36. SMTC Window Frame Sides (2)
37. SMTC Window Frame Top-Bottom
38. SMTC Window Panel Gasket
39. SMTC Window Panel
40. SMTC Intermediate Panel
41. SMTC Rear Panel
42. SMTC Top Chip Shield
43. SMTC Panel Top Support
44. SMTC Cylinder Shield
45. Rear Apron
46. Rear Pan
47. Rear Panel